

Beating Wood Rot

by Tom O'Brien



Use borate-based wood preservatives to stop decay and epoxy to repair the damage

Wood rot is a far bigger problem nowadays than it was in years past. That's primarily because today's fast-growth lumber is much less forgiving of sloppy construction or deferred maintenance than the hardy, old-growth species our ancestors built their homes with. On the bright side, however, technology has improved as resources have declined. High-strength-epoxy wood-repair systems used in combination with borate-based wood preservatives make it possible to not only repair rot-damaged wood but practically guarantee that the rot won't return. None of these products are cheap, though, so it's essential to know when, where, and how to use them most effectively.

Inspection and Excavation

Not every rotten piece of wood can — or should — be repaired. Readily available trim elements that are easily removable (such as brick mold and fascia boards) are simply not worth the time and materials to fix unless the damage is minimal. Strong candidates for epoxy repair include expensive components like porch and stair parts, hard-to-remove elements like window sills, and historic pieces like moldings or turnings that would require custom replication.

As with an iceberg, the vast majority of rot damage is beneath the surface. Before you can decide whether repair is feasible, you

Beating Wood Rot



Figure 1. A painter's 5-in-1 is the perfect tool to carve into rot-damaged wood and excavate the black, punky detritus (top). After the worst of the damage has been removed, a solution of powdered borate and water is sprayed on the affected surfaces to kill the rot organism (center). To quickly attack deeply buried rot, a borate gel is injected into a few small holes that have been drilled into the center of the wood (above).

must determine the extent of the decay. I start with a painter's 5-in-1 tool, carving into the loose, punky decay as if I were cleaning out a pumpkin (see Figure 1). After I reach sound wood — it may be discolored but should be solidly attached — I use a scratch awl to poke around the inside of the crevice, like a dentist with a pick, searching for soft spots I may have overlooked. To verify that the surrounding wood is sound, I also drill a few exploratory $\frac{3}{16}$ -inch holes around the outside edges of the crevice.

When I'm satisfied that the damage is contained, I scrape away the paint along the edges of the repair area, then blow out the loose debris and dust with compressed air. Cleanliness is one key to a successful repair; dryness is another.

Fighting the fungus. Rot spores are present in most untreated wood. The wood provides a food source, but the organism needs moisture and warm temperatures in order to chow down and replicate. As long as the moisture content stays low (20 percent or less), the fungus will remain dormant. Since I cannot rest assured that my clients will diligently maintain their property after I'm gone, I apply a borate-based wood preservative that kills the rot fungus and prevents its return. I typically use a product called Board Defense, a powdered concentrate that's mixed with water and applied with a sprayer. After thoroughly soaking down all of the affected surfaces, I allow them to dry completely before I begin making the repairs.

The liquid treatment gradually absorbs into the wood and kills hidden rot, but if I'm repairing a particularly large or heavily damaged structure (such as a column base), I'll drill a few $\frac{1}{4}$ -inch holes into the center of the piece and inject a highly concentrated borate gel called Jecta. I purchase all of the borates I use — and some of the epoxies — from Wood Care Systems (800/827-3480, ewoodcare.com), which provides first-rate customer service.

Epoxy Work

Assuming that the source of the moisture intrusion that set off the rot has been identified and corrected, drying time can vary from overnight to a week or more, depending on the extent of the damage. If rain is expected, I cover the object with a tent of 6-mil poly and secure it with duct tape. I now use a Delmhorst moisture meter (877/335-6467, delmhorst.com) to determine when the wood is acceptably dry, but for many years I relied on touch and feel — if in doubt, I would give it a few more days.

Supplies. Epoxies have a limited working time, so it's crucial to assemble all the necessary tools and materials before you begin mixing. I keep a pair of tool kits well-stocked with latex gloves, plastic putty knives, disposable paint brushes, small plastic cups, stirring sticks, and a variety of other necessities in



Figure 2. Dedicated tool kits keep the various epoxies and supplies well-organized and readily at hand.

addition to the epoxy consolidants and fillers (Figure 2).

As to whose products to buy, I've used most — if not all — of the major brands, and I have no complaint about the quality of any manufacturer's offerings. Some products are more user-friendly than others; some are more adjustable in terms of viscosity; and some are conveniently available over the counter at local supply houses (whereas others are obtainable only by mail-order). But all of the epoxies that are specifically marketed for wood restora-

tion will get the job done as long as you follow the directions.

Consolidation. When the damaged piece is completely dry and I'm certain that the ambient temperature won't dip below 50°F, I begin the repair by saturating the rot-affected wood with a low-viscosity liquid epoxy. After it soaks into the wood fibers, this consolidant will harden to provide reinforcement and promote a strong bond between old wood and new epoxy filler (see sidebar, "How Much Rot Should You Remove?," below).

How Much Rot Should You Remove?

Within the restoration community, opinions differ strongly on how much decay must be removed to ensure a successful epoxy repair.

Practitioners of the "consolidation" approach — which I describe in this article — first scrape away the loose debris with hand tools, then treat the rot-damaged wood that remains firmly attached with a liquid epoxy consolidant that fortifies the wood and promotes bonding with the epoxy filler. This technique is promoted by manufacturers like Abatron (abatron.com), ConServ Epoxy (conservepoxy.com), and System Three (systemthree.com).

Some restoration specialists question the wisdom of leaving any blighted wood behind. Thus, after the handwork is done, they

attack the damaged surface with a powered carving tool — such as a Dremel or a die grinder — and shave away until nothing but pristine wood remains. Then they coat the spotless surface with a liquid epoxy "primer" and fill the cavity with epoxy. I call this the "get it all" approach: It's straightforward and idiot-proof but requires more invasive surgery than consolidation. West System (westsystem.com) and Advanced Repair Technology (advancedrepair.com) recommend this method.

Having used both techniques many times, I'm convinced that you can achieve excellent results with either. When it comes to epoxy repair, meticulous work and attention to detail is far more important than which technique or product you use.



An alternative to fortifying rot-softened wood fibers with an epoxy consolidant is to remove all of the suspect material with a power tool — such as the die grinder shown here, which is equipped with a 1/2-inch-diameter core box bit.

Beating Wood Rot

Nontoxic Rx for Rot

Borate-based wood preservatives kill wood rot and fungi on contact. They also exterminate any wood-destroying insects — like termites, carpenter ants, and powder-post beetles — that ingest the treated wood. Yet borates are no more toxic to higher life forms than table salt.

I use borates not only to wipe out active rot infestations but to keep these organisms from getting a foothold in the first place. If I'm making porch repairs, for example, and notice that the bottom sides of the floorboards are unpainted — as they often are — I'll mix up some Board Defense (a powdered concentrate containing borates) and apply it with a pump sprayer. Other candidates for extra protection include rafter tails, non-pressure-treated sill plates, and subfloors in bathrooms and kitchens.

Borate protection is also available in time-release capsules. Impel Rods are crystalline tubes of boric acid that slowly dissolve when exposed to water. To protect a precious wood member, you simply drill a hole, insert the appropriate-sized Impel Rod, and cap the hole with putty or a removable plug. If the wood stays dry, the rod remains intact; if it gets wet, the borates will diffuse and kill off any rot infestations before they can do any damage.

In extreme cases, the water solubility that makes borates so effective can be a drawback, because prolonged exposure to moisture can cause borate-based preservatives to leach out and lose their effectiveness. I use Impel Rods as backup protection, in case the primary moisture barriers fail — but businesses like marinas and electric utilities use them as primary protectors for their pilings and poles. They simply cover the rods with removable plugs and regularly insert replacements.



After drilling a hole, the author inserts an Impel Rod — a crystalline, water-soluble form of borate — to help prevent rot infestations (left). To protect a window's most vulnerable surfaces, he inserts small Impel Rods into holes drilled into the face of the window sill and injects Jecta into a couple of tiny holes placed near the bottom of the casing (below). Then he plugs the holes with epoxy wood filler.



Impel Rods are sold in a range of sizes; the smallest is about the size of a prescription-drug capsule (1/4 inch in diameter and 1/2 inch long) and the largest is as big as the bottle those pills come in (3/4 inch in diameter and 3 inches long). I use the smaller sizes to protect valuable features like porch railings, corner boards, door bottoms, window sills, and casings. I use the larger ones for heftier members like fence posts, porch columns, and girder beams.

All of these products are available by mail order from Wood Care Systems (800/827-3480, ewoodcare.com).



Figure 3. Drilling a series of small holes around the perimeter of a rot-damaged crevice (left) makes it possible to inject epoxy consolidant deep into the wood. To fully saturate the damaged area, the author alternates between squirting consolidant into the holes and brushing it on the surface (below).

Brushing the liquid epoxy on the surface adequately consolidates shallow damage. When I'm treating deeper wounds, however, I encircle the crevice with a series of $\frac{3}{16}$ -inch holes, taking care to stop the drill bit short of the bottom of the wood (**Figure 3**). I'll use these holes as injection points to saturate the damaged area with consolidant.

After a final cleanup to remove the sawdust from the drilling operation, it's time to mix the consolidant. Liquid epoxy clings tenaciously to any surface it lands on, so I lay out drop cloths when working around brick or stone, and I always wear latex gloves. On large jobs, I'll slip on two pairs or more; if one gets messy I can simply peel it off and keep going. I mix up a batch of consolidant by pouring the specified amounts of resin and hardener into an 8-ounce hair-dye bottle — the kind with a nozzle top and 1-ounce graduations on the side — then stir the mixture thoroughly with a tongue depressor or a strip of cedar shim.

After pouring some of the liquid into a plastic cup for brushing, I screw the nozzle top onto the bottle and inject consolidant into each of the holes I drilled. As the liquid soaks into the wood, I alternate between brushing it on the exposed surfaces and refilling the holes. I don't stop until the holes remain full and the surface of the damaged wood has glossed over. I usually allow the consolidant an hour or two to air dry, but if pressed for time, I'll begin the filling work right away.

Gap filling. The mixing procedure for epoxy filler depends on the brand used. In some cases you add one or more powdered thickening agents to a two-part liquid epoxy. In others you combine two lumps of putty and knead them together as if making bread. One manufacturer conveniently packages its resin and hardener separately in conjoined caulking tubes, so all you do is squeeze



Figure 4. Using a plastic putty knife, the author presses the epoxy paste firmly into the crevice, then wipes the surface smooth (left). After the epoxy has fully cured, he begins the tooling process by shaving down the rough spots with a Surform plane (below).



Beating Wood Rot



Figure 5. Specialty sanders, like this Bosch compact belt sander (above), are indispensable for finishing an epoxy patch. For paint-grade work, a random orbit sander loaded with 100-grit paper makes the patch disappear (right). No repair is complete until both the epoxy and the bare wood surfaces are sealed with a premium epoxy-compatible primer, followed by two coats of top-quality acrylic paint (below).



the trigger a few times and mix the two parts on a flat surface.

After the paste is mixed, I spread the material out in a thin layer to dissipate the heat generated by the curing process, and maximize its working time (**Figure 4, page 5**). For small repairs — those that require a baseball-sized mass of filler or less — I pack the void tightly and wipe the surface smooth using a disposable putty knife. If the filler “pulls” during this process, I lubricate the edge of the knife with a bit of leftover consolidant. The consolidant makes the cured surface a bit harder to sand, but it saves the hassle of taking an extra day to apply a skim coat.

Large repairs are more problematic than small ones. One complication is heat buildup: A large mass of curing epoxy can generate enough heat to start a fire, especially on a hot day. (Trust me, I’ve seen it happen.) The other problem is that a large mass of epoxy filler is very expensive.

To prevent excessive heat buildup, epoxy manufacturers suggest building up the repair in 1-inch-thick layers. A better solution — in terms of time as well as cost and safety — is to use small blocks of clean, dry wood as aggregate; I keep a bag full of blocks of various sizes in one of my kit buckets.

I begin a large repair by coating the inside of the cavity with a thick layer of epoxy paste. Next I butter the blocks on all sides with paste and press them firmly into the hole, making sure that the paste oozes out on all sides. I try to leave 1/2 inch between each of the blocks and an equal distance between the outermost blocks and the surface. After wiping the top layer smooth, I leave the repair to cure overnight, covered with plastic if rain or cool temperatures are expected.

I clean up the putty knives and hair-dye bottles, and any other supplies I plan to reuse, by rinsing them with white vinegar.

Tooling. After it’s fully cured, the epoxy patch is as easy to shape as joint compound. Wood chisels and a Stanley Surform plane quickly knock down the high spots. A random orbit sander and one or more detail sanders make the patch disappear (**Figure 5**).

Final protection. To ensure that the repair is fully protected from the elements, I cover the epoxy and any exposed wood surfaces with an epoxy-compatible primer, caulk every open joint, and apply two coats of a top-quality acrylic paint.

Tom O’Brien is a freelance writer and longtime restoration carpenter who lives in New Milford, Conn.